



FireWire™ Comfort Connection

Are you the owner of a FireWire™ controller with a so far “unused” internal FireWire™ connector? Do you also have to crawl under your desk, poking and fiddling in the dark until the connector fits properly. Rescue is here! With the Cameo Connect the internal FireWire™ port can easily be routed to the front of your PC. Integrated into a 5¼” metal drive bay frame, equipped with a connector for the PC power supply and the ability to install 3½” devices. Even 3½” devices using removable media can be installed due to the exchangeable faceplate.



Of course, an adequately long FireWire™ cable is included to connect your FireWire™ controller to the Cameo Connect.

Cameo Connect. Showing what you’ve got .

Technical Details

- 5 ¼“ Front drive bay module with face plate
- Internal 6Pin IEEE-1394 FireWire™ connector
- External 6Pin IEEE-1394 FireWire™ connector
- Internal connector to PC power supply (Floppy type power connector)
- Y cable for power supply
- Shielded 0.6m FireWire™ cable (6 pin/6 pin)

System Requirements

- 1 free 5¼“ drive bay
- FireWire™ card with internal 6 pin IEEE-1394 FireWire™ connector (e.g. TerraTec Cameo 400 DV)

System Recommendation

- 1 free 5¼“ drive bay
- TerraTec Cameo 400 DV

Compatibility**

- ADS PYRO 1394DV
- ADS PYRO PlatinumDV (PCI)
- ADS PYRO ProDV (PCI)
- ADS PYRO BasicDV (PCI)
- Canopus DVRaptor
- DPS Spark
- DPS Spark Plus
- Exsys EX-6500
- Guillemot DV Action
- Fast DV Master
- Pinnacle Systems DV200
- Pinnacle Systems DV500 Plus
- Pinnacle Studio DV 1.03
- TerraTec Cameo 400 DV
- TerraTec Cameo 200 DV
- e.t.c.

Art.No: 1424 EAN-Code: 4017273674243

Warranty: 24 month

*) The weight information applies only to the single module

**) FireWire™ controller from other vendors that have an internal FireWire™ connector. Without any warranty